Maintenance Schedule for Normal Conditions

| Service at the indicated distance or time-whichever comes first | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | miles x 1000 | 7.5 | 15 | 30 | 45 | 60 | 75 | 90 | 105 | 120 | | | |
| | km x 1000 | 12 | 24 | 48 | 72 | 96 | 120 | 144 | 168 | 192 | | | |
| Check engine oil and coolant | | Check oil and coolant at each fuel stop | | | | | | | | | | | |
| Replace engine oil | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Rotate tires (Check tire inflation & condition at least once per month) | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Replace engine oil filter | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Inspect front and rear brakes | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Check parking brake adjustment | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Visually inspect the following items | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Tie rod ends | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Suspension components | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Driveshaft boots | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Brake hoses and lines (including ABS) | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| All fluid levels & condition of fluids | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| *Exhaust system | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| *Fuel lines & connections | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | |
| Inspect and adjust drive belt | | | | ■ | | ■ | | ■ | | ■ | | | |
| Replace dust and pollen filter | | | | ■ | | ■ | | ■ | | ■ | | | |
| Replace transmission fluid | MT | | | | | | | ■ | | | | | |
| | AT | | | | | | | ■ | | | | | |
| Inspect idle speed | | | | | | | | | ■ | | | | |
| Replace rear differential fluid (4WD) | | | | | | | | ■ | | | | | |
| ***Service the following items at recommended intervals.*** | | | | | | | | | | | | | |
| Replace air cleaner element | | Every 30,000 miles (48,000 km) | | | | | | | | | | | |
| Replace timing belt, water pump, drive belt and engine coolant | | Every 105,000 miles or 7 years, whichever comes first | | | | | | | | | | | |
| Replace spark plugs | | Every 110,000 miles (176,000 km) | | | | | | | | | | | |
| Inspect valve clearance | | Inspect every 105,000 miles (168,000 km), otherwise adjust only if noisy | | | | | | | | | | | |
| Replace engine coolant | | Replace at 45,000/75,000/105,000 miles | | | | | | | | | | | |
| Replace brake fluid | | Every 45,000/75,000 miles | | | | | | | | | | | |
| *: Replace at 120,000 miles or 6 years, then every 90k miles or 5 years | | $52.94 | $52.94 | $230.89 | $177.89 | $230.89 | $122.93 | $495.81 | $672.92 | $230.89 | | | |
| #: See information on maintenance & emissions warranty | | | | | | | | | | | | | |

Brake Fluid Flush: 124.95+tax