Maintenance Schedule for Normal Conditions

Service at the indicated distance or time-whichever comes first	miles x 1000	7.5	15	30	45	60	75	90	105	120			
	km x 1000	12	24	48	72	96	120	144	168	192			
Check engine oil and coolant		Check oil and coolant at each fuel stop											
Replace engine oil		■	■	■	■	■	■	■	■	■			
Rotate tires (Check tire inflation & condition at least once per month)		Rotate tires every 7,500 miles (12,000 km)											
Replace engine oil filter		■	■	■	■	■	■	■	■	■			
Inspect front and rear brakes			■	■	■	■	■	■	■	■			
Check parking brake adjustment			■	■	■	■	■	■	■	■			
Visually inspect the following items			■	■	■	■	■	■	■	■			
Tie rod ends			■	■	■	■	■	■	■	■			
Suspension components			■	■	■	■	■	■	■	■			
Driveshaft boots			■	■	■	■	■	■	■	■			
Brake hoses and lines (including ABS)			■	■	■	■	■	■	■	■			
All fluid levels & condition of fluids			■	■	■	■	■	■	■	■			
*Exhaust system			■	■	■	■	■	■	■	■			
*Fuel lines & connections			■	■	■	■	■	■	■	■			
Inspect and adjust drive belt				■		■		■		■			
Replace dust and pollen filter				■		■		■		■			
Replace transmission fluid AT					■		■		■				
Replace timing belt, water pump, drive belt, and engine coolant		Every 105,000 miles or 7 years, whichever comes first											
Inspect idle speed									■				
Replace rear differential fluid (4WD)		Vehicle is not euipped with a rear differential											
Service the following items at recommended intervals.													
Replace air cleaner element		Every 30,000 miles (48,000 km)											
Replace spark plugs		Every 105,000 miles (168,000 km)											
Inspect valve clearance		Inspect 105,000 miles and/or adjust if noisy											
Replace engine coolant		Replace at 45,000/75,000/105,000 miles											
Replace brake fluid		Replace at 45,000 and 90,000 miles											
		$52.94	$52.94	$171.77	$327.87	$171.77	$202.92	$296.72	$969.03	$171.77			
#: See information on maintenance & emissions warranty													

Brake Fluid Flush: 124.95+tax