Maintenance Schedule for Normal Conditions

Service at the indicated distance or time-whichever comes first		miles x 1000	7.5	15	30	45	60	75	90	105	120			
		km x 1000	16	32	48	64	80	96	112	128	144			
Check engine oil and coolant			Check oil and coolant at each fuel stop											
Replace engine oil			■	■	■	■	■	■	■	■	■			
Replace engine oil filter			■	■	■	■	■	■	■	■	■			
Tire Rotation			Rotate tire every 7,500 miles (12,000 km)											
Inspect front and rear brakes				■	■	■	■	■	■	■	■			
Check parking brake adjustment				■	■	■	■	■	■	■	■			
Visually inspect the following items				■	■	■	■	■	■	■	■			
Tie rod ends				■	■	■	■	■	■	■	■			
Suspension components				■	■	■	■	■	■	■	■			
Driveshaft boots				■	■	■	■	■	■	■	■			
Brake hoses and lines (including ABS)				■	■	■	■	■	■	■	■			
All fluid levels & condition of fluids				■	■	■	■	■	■	■	■			
*Exhaust system				■	■	■	■	■	■	■	■			
*Fuel lines & connections				■	■	■	■	■	■	■	■			
Inspect and adjust drive belt					■		■		■		■			
Replace dust and pollen filter					■		■		■		■			
Replace transmission fluid	MT								■					
	AT								■					
Inspect idle speed										■				
Replace rear differential fluid (4WD)			Vehicle not equipped with a rear differential											
Service the following items at recommended intervals.														
Replace air cleaner element			Every 30,000 miles (48,000 km)											
Replace timing belt, water pump, drive belts, and engine coolant										■				
Replace spark plugs			Replace at 105,000 miles (168,000 km)											
Inspect valve clearance			Inspect every 30,000 miles, otherwise adjust only if noisy											
Replace engine coolant			At 45,000/75,000/105,000 miles											
Replace brake fluid			Replace at 45,000/90,000 miles											
*: Replace at 120,000 miles or 6 years, then every 90k miles or 5 years			$52.94	$52.94	$171.77	$247.88	$171.77	$132.93	$376.71	$809.32	$52.94			
#: See information on maintenance & emissions warranty														

Brake Fluid Flush: 124.95+tax