Maintenance Schedule for Normal Conditions

Service at the indicated distance or time-whichever comes first	miles x 1000	7.5	15	30	45	60	75	90	105	120			
	km x 1000	16	32	48	64	80	96	112	128	144			
Check engine oil and coolant		Check oil and coolant at each fuel stop											
Replace engine oil		■	■	■	■	■	■	■	■	■			
Rotate tires (Check tire inflation & condition at least once per month)		■	■	■	■	■	■	■	■	■			
Replace engine oil filter		■	■	■	■	■	■	■	■	■			
Inspect front and rear brakes			■	■	■	■	■	■	■	■			
Check parking brake adjustment			■	■	■	■	■	■	■	■			
Visually inspect the following items			■	■	■	■	■	■	■	■			
Tie rod ends			■	■	■	■	■	■	■	■			
Suspension components			■	■	■	■	■	■	■	■			
Driveshaft boots			■	■	■	■	■	■	■	■			
Brake hoses and lines (including ABS)			■	■	■	■	■	■	■	■			
All fluid levels & condition of fluids			■	■	■	■	■	■	■	■			
*Exhaust system			■	■	■	■	■	■	■	■			
*Fuel lines & connections			■	■	■	■	■	■	■	■			
Inspect and adjust drive belt				■		■		■		■			
Replace dust and pollen filter				■		■		■		■			
Replace transmission fluid AT					■		■		■				
Replace timing belt, water pump, drive belts, and engine coolant									■				
Inspect idle speed									■				
Replace rear differential fluid (4WD)			■	■		■		■		■			
Service the following items at recommended intervals.													
Replace air cleaner element		Every 30,000 miles (48,000 km)											
Replace spark plugs		Every 105,000 miles (128,000 km)											
Inspect valve clearance		Adjust only if noisy, Inspect at 105,000 miles											
Replace engine coolant		At 120,000 miles (192,000 km) or 10 years, then every 60k miles (96,000 km) or 5 years											
Replace brake fluid		Every 3 years (independent of mileage)											
		$52.94	**$112.93**	**$231.76**	**$132.93**	**$231.76**	**$132.93**	**$231.76**	**$888.54**	**$231.76**			
#: See information on maintenance & emissions warranty													

Brake Fluid Flush: 124.95+tax